

INSTRUCTION

20-2016





Bocaro

611988.004


IP 66 IK06

 220 - 240 V / 50 Hz

 3 x 2,5 mm²
 2,50 mm²



611988.004	L 120, B 120, H 1100	LED	20 W	5,6 kg
Φ	EEK _{LED}	EEK	CRI	CCT
1600 lm	A+	A+	83	3000K
B10	B16	C10	C16	
150	150	150	150	











Die Leuchte darf nur mit ihren vollständigen Schutzabdeckungen betrieben werden.
The luminaire must be used with its complete protective covers only.





EN 12464

EN 12464


EN 12464
Wartungsplan/
Maintenance
schedule

RZB
Rudolf Zimmermann,
Bamberg GmbH
 Rheinstraße 16
 D-96052 Bamberg
 Deutschland
 Telefon +49 951/79 09-0
 Telefax +49 951/79 09-198
 www.rzb.de
 info@rzb-leuchten.de







	982103.010 L 120, B 120, H 401 1,3 kg
--	---